

RRD-HN4S-XX – 4 BUTTON W/ RAISE/LOWER HYBRID KEYPAD



This is the 4 Button w/ Raise/Lower Hybrid Keypad. **Check out the RadioRA 2 products page here.**

- Keypad buttons are programmable to select scene or room preset levels or positions.
- At the press of a keypad button, lights fade ON or OFF to desired levels and shades/draperies open or close to desired positions.
- Prepaid engraving included. Redeemable for one engraved Replacement Button Kit.
- Internal dimmer is assigned to top button by default. Tap top button to toggle load ON / OFF.
- Internal dimmer can be assigned to any button on the C • L ® Hybrid Keypad and can be programmed to be controlled by any keypad.